

VORTAC ODI <b>117.9</b> Chan <b>126</b>	APP CRS <b>083°</b>	Rwy Idg TDZE Apt Elev	<b>4697</b> <b>829</b> <b>839</b>
---	------------------------	-----------------------------	---

VOR RWY 11  
SPARTA/FORT MC COY (CMY)

DME required.	MISSED APPROACH: Climbing right turn to 4000 on heading 295° and on ODI R-083 to ODI VORTAC and hold.
▼ Rwy 11 helicopter visibility reduction below 1 SM NA. When local altimeter setting not received, use LSE altimeter setting and increase all MDAs 80 feet. ▲ Straight-in Rwy 11 NA at night, Circling Rwy 11, 19, 29 NA at night.	

ASOS <b>119.775</b>	VOLK APP CON ★ <b>135.25 244.875</b>	SPARTA/MC COY TOWER ★ <b>124.6 254.375</b>	GND CON <b>123.625</b>	CTAF <b>124.6 0</b>
------------------------	---	---	---------------------------	------------------------

