

25163

MISSED APPROACH: Climb to 1100 then climbing right turn to 4000 on DXO VOR/DME R-297 to DOHNT INT/DXO 15.5 DME/RADAR and hold.

ILS PRM Z RWY 22R (SA CAT I & II) (CLOSE PARALLEL)