

VOR-A
HARTFORD-BRAINARD (HFD)

MISSED APPROACH: Climbing right turn to 2500 on heading 100° and PUT VOR/DME R-265 to RAMBO INT and hold.

[illegible]

2500
hdg 100°

PUT R-265

RAMBO INT

HFD VOR/DME

One Minute Holding Pattern

MAVDE HFD 7.1

ZOVOX HFD 4.8

1200

2.3 NM

4.8 NM

154°

334°

2500

CATEGORY	A	B	C	D
CIRCLING	1200-1½ 1182 (1200-1¼)	1200-1½ 1182 (1200-1½)	1200-3	1182 (1200-3)

ZOVOX FIX MINIMUMS (DME REQUIRED)

CIRCLING	580-1 562 (600-1)	900-1¼ 882 (900-1½)	920-2¾ 902 (1000-2¾)	920-3 902 (1000-3)
----------	----------------------	------------------------	-------------------------	-----------------------