



NDB SJ <u>356</u>	APP CRS 038°	Rwy Idg 5940 TDZE 1917 Apt Elev 1919
-----------------------------	------------------------	-----------------------------------------------------------------

NDB RWY 3

SAN ANGELO RGNL/MATHIS FLD (SJT)

 For inop ALS, increase Cat A/B visibility to RVR 5500, and Cat C/D to 2 SM.	 MALSR	MISSED APPROACH: Climbing right turn to 4000 direct SJ NDB and hold.			
		ATIS 128.45 319.0	SAN ANGELO APP CON ★ 125.35 354.1	MATHIS TOWER ★ 118.3(CTAF) 0 284.7	GND CON 121.9 348.6

