

LOC I-SBN	APP CRS	Rwy Ldg
109.3	274°	8412
		TDZE
		774
		Apt Elev
		798

ILS RWY 27L (SA CAT I & II)
SOUTH BEND INTL (SBN)

ADF and RADAR required.		MALSR	MISSED APPROACH: Climb to 1500 then climbing right turn to 3000 direct MISHA LOM/RADAR and hold, continue climb-in-hold to 3000.	
▼ Procedure NA when tower closed. Requires specific OPSPEC, MSPEC, or LOA approval.		⚡		
ATIS	SOUTH BEND APP CON ★	SOUTH BEND TOWER ★	GND CON	CLNC DEL
120.675	118.55 257.8	135.675 (CTAF) 257.8	121.7	121.9

