

LOC I-SBN	APP CRS	Rwy Ldg	8412
109.3	274°	TDZE	774
		Apt Elev	798

ILS or LOC RWY 27L

SOUTH BEND INTL (SBN)

ADF and RADAR required.		MALSR AS	MISSED APPROACH: Climb to 1500 then climbing right turn to 3000 direct MISHA LOM/RADAR and hold, continue climb-in-hold to 3000.	
<div><div></div><div>Circling Rwy 27R NA at night.</div><div><div></div><div>* RVR 1800 authorized with use of FD or AP or HUD to DA.</div></div></div>				
ATIS 120.675	SOUTH BEND APP CON ★ 118.55 257.8	SOUTH BEND TOWER ★ 135.675 (CTAF) 257.8		GND CON 121.7
				CLNC DEL 121.9

