

WAAS CH <b>50108</b> <b>W27A</b>	APP CRS <b>274°</b>	Rwy Ldg <b>8412</b> TDZE <b>774</b> Apt Elev <b>798</b>
--	------------------------	---

RNAV (GPS) RWY 27L

SOUTH BEND INTL (SBN)

RNP APCH - GPS			MALSR	MISSED APPROACH: Climb to 2600 direct TOKOC and hold.
For uncompensated Baro-VNAV systems, LNAV/VNAV NA below -19°C or above 54°C. Circling to Rwy 27R NA at night. For inop ALS, increase LNAV Cat C/D visibility to 1½ SM.				
ATIS <b>120.675</b>	SOUTH BEND APP CON★ <b>118.55 257.8</b>	SOUTH BEND TOWER★ <b>135.675 (CTAF) 0 257.8</b>	GND CON <b>121.7</b>	CLNC DEL <b>121.9</b>

