

AUSTIN-BERGSTROM INTL (AUS)

MISSED APPROACH: Climb to 1000 then climbing right turn to 3000 direct HOOK and hold.

CPDLC

