

VORTAC BRO

116.3

Chan 110

APP CRS

311°

Rwy Ldg

7257

TDZE

36

Apt Elev

36

VOR Y or TACAN RWY 31

VALLEY INTL (HRL)

DME required.

When local altimeter setting not received, use Port Isabel altimeter setting and increase all MDAs 60 feet.

MALSR

MISSED APPROACH: Climbing right turn to 2000 on BRO R-311 to ZOCKE/12 DME and hold.

ATIS 124.85	VALLEY APP CON 120.7 279.5	HARLINGEN TOWER ★ 119.3 (CTAF) 317.6	GND CON 121.7	UNICOM 122.95
----------------	-------------------------------	---	------------------	------------------

