

LOC/DME I-OME	APP CRS	Rwy Idg	6009
108.7	279°	TDZE	25
Chan 24		Apt Elev	41

ILS Z or LOC Z RWY 28

NOME(OME)(PAOM)

DME required.	MALSRR	MISSED APPROACH: Climb to 1100 then climbing left turn to 3000 direct OME VOR/DME and hold, continue climb-in-hold to 3000.
<div><div>▼</div><div>▲</div></div> <div>Circling Rwy 21 NA at night. Circling NA for Cats C and D north of Rwy 10-28. Inop table does not apply to S-ILS 28 all Cats and S-LOC 28 Cats A and B. For inop ALS, increase S-LOC 28 Cats C and D to RVR 6000.</div>	<div><div>AS</div><div></div></div>	

AFIS	ANCHORAGE CENTER	NOME RADIO
119.925	133.3 290.4	123.6 (CTAF) 0

