

LOC/DME I-FAI	APP CRS	Rwy Idg	11050
110.3	203°	TDZE	439
Chan 40		Apt Elev	439

ILS Z or LOC Z RWY 20R

FAIRBANKS INTL (FAI) (PAFA)

DME required. DME required for procedure entry.

MALSR

MISSED APPROACH: Climb to 1100 then climbing left turn to 3000 on FAI VORTAC R-107 to KRNL/FAI VORTAC 13 DME and hold.

ATIS	FAIRBANKS APP CON	FAIRBANKS TOWER	GND CON	CLNC DEL
124.4	125.35 363.2	118.3 257.8	121.9	127.6

