



DEPARTURE ROUTE DESCRIPTION

TAKEOFF RUNWAY 4: Climbing right turn heading 100° and LVM VOR/DME R-070 outbound; aircraft departing eastbound, climb via LVM R-070/V2-86 enroute. All others continue climb on LVM R-070 to 7800, then climbing left via heading 260° and LVM R-050 to cross LVM VOR/DME at or above 9000, then climb enroute.

TAKEOFF RUNWAY 22: Climbing right turn heading 270° and LVM VOR/DME R-246 outbound; aircraft departing eastbound, continue climb via LVM R-246 outbound to 6600, then climbing right turn direct LVM VOR/DME, then climb on LVM R-070/V2-86 enroute. All other aircraft continue climb via LVM VOR/DME R-246 and BZN VOR/DME R-110 to BZN. Obtain ATC approval for VCOA when requesting IFR clearance. For climb in visual conditions, cross LVM VOR/DME at or above 9000 before proceeding via filed airway route.