

SBJ VOR/DME <b>112.9</b> Chan <b>76</b>	APP CRS <b>240°</b>	Rwy Idg TDZE Apt Elev	<b>N/A</b> <b>N/A</b> <b>394</b>
---	------------------------	-----------------------------	--

VOR-A  
DOYLESTOWN (DYL)

DME required.		<p>MISSED APPROACH: Climbing right turn to 2200 on SBI VOR/DME R-240 to GROOM/17.8 DME and hold.</p>	
<p><b>▼</b> When local altimeter setting not received, use Trenton altimeter setting and increase all MDAs 80 feet.</p> <p><b>▲</b></p>			
<p>ASOS <b>118.875</b></p>	<p>PHILADELPHIA APP CON <b>123.8 291.7</b></p>	<p>CLNC DEL <b>118.55</b></p>	<p>UNICOM <b>122.975 (CTAF)</b> <b>📢</b></p>

Procedure NA for arrival  
on SBJ VOR/DME  
airway radials 237 CW 295.

