

LOC/DME I-SCC

109.3

Chan 30

APP CRS

058°

Rwy Idg

6500

TDZE

67

Apt Elev

67

ILS or LOC RWY 6

DEADHORSE (SCC) (PASC)

DME required.

For inop ALS, increase S-ILS 6 Cat E visibility to RVR 4000 and S-LOC 6 Cats C/D/E to RVR 4500.

*RVR 1800 authorized with use of FD or AP or HUD to DA.

MALSR

MISSED APPROACH: Climb to 1500 then climbing right turn to 4000 on heading 170° and SCC VOR/DME R-144 to UVALL/SCC 16 DME and hold.

AFIS 118.4	ANCHORAGE CENTER 134.4 370.9	DEADHORSE RADIO 123.6 (CTAF) 0
---------------	---------------------------------	-----------------------------------

Diagram illustrating the ILS approach for RWY 6 at Deadhorse, Alaska. The diagram shows the approach path, including the 2300 NoPT, 2300 to JOVVO, and 2300 to JOVVO to ARCON. Key altitudes and frequencies are marked, such as 2300, 1900, 1600, 1500, 4000, and 170°. The diagram also shows the 2300 NoPT, 2300 to JOVVO, and 2300 to JOVVO to ARCON. Key altitudes and frequencies are marked, such as 2300, 1900, 1600, 1500, 4000, and 170°. The diagram also shows the 2300 NoPT, 2300 to JOVVO, and 2300 to JOVVO to ARCON. Key altitudes and frequencies are marked, such as 2300, 1900, 1600, 1500, 4000, and 170°.

ELEV 67

TDZE 67

One Minute Holding Pattern

6000 2300 058°

GS 3.00° TCH 58

JOVVO I-SCC 15.7

FEVLE I-SCC 10.8

CIMAS I-SCC 5.9

WUKTI I-SCC 4

I-SCC 2

I-SCC 1.3

1500

4000

SCC R-144

UVALL

Use I-SCC DME when on the localizer course.

6000 2300 058°

058°

1900

1600

980

4.9 NM

4.9 NM

1.9 NM

0.8

CATEGORY	A	B	C	D	E
S-ILS 6*	267/24 200 (200-1/2)				
S-LOC 6	360/24 293 (300-1/2)				
CIRCLING	540-1 473 (500-1)		580-1 513 (600-1 1/2)		620-2 553 (600-2)

DEADHORSE, ALASKA

Amtd 5 05SEP24

70°12'N-148°28'W

DEADHORSE (SCC) (PASC)

ILS or LOC RWY 6