


VORTAC BTG <b>116.6</b> Chan <b>113</b>	APP CRS <b>255°</b>	Rwy Ldg TDZE Apt Elev	<b>N/A</b> <b>N/A</b> <b>58</b>
---	------------------------	-----------------------------	---------------------------------------

VOR/DME-A  
SCAPPOOSE (SPB)

- |  |  |   |
|--|--|---|
| <br> | <p>Circling to Rwy 15 NA at night. Circling NA west of Rwy 15-33. When local altimeter setting not received, use Portland Intl altimeter setting; increase all MDAs 40 feet. Increase Circling Cat D visibility <math>\frac{1}{4}</math> SM.</p> | <p>MISSED APPROACH: Climbing right turn to 4200 direct BTG VORTAC and hold, continue climb-in-hold to 4200.</p> |
|--|--|---|

ASOS <b>135.875</b>	PORTLAND APP CON <b>124.35 299.2</b>	CLNC DEL <b>121.65</b>	UNICOM <b>122.8 (CTAF) 0</b>
------------------------	---	---------------------------	---------------------------------

