

APP CRS
004°

Rwy Idg
TDZE
Apt Elev

3244
125
125

RNAV (GPS) RWY 36
WATTS-WOODLAND (O41)

▼

NA

DME/DME RNP- 0.3 NA.
Procedure NA at night.
Use Sacramento Intl altimeter setting; when not received,
use Sacramento Exec altimeter setting and increase all
MDA 20 feet.

MISSED APPROACH: Climbing left turn to 3000 direct CEVIT
and hold.

TRAVIS APP CON
126.6 281.45

UNICOM
122.8 (CTAF) 0

