

<div><div>▼</div><div>▲ NA</div></div> <div>DME required. Procedure NA at night. Use Fayetteville alimeter setting.</div>	MISSED APPROACH: Climbing left turn to 3000 on FAY VOR/DME R-271 to RAEFO/FAY 25 DME and hold.
FAYETTEVILLE APP CON 127.8 290.25	UNICOM 123.0 (CTAF)

