

VORTAC PKE	APP CRS	Rwy Idg	N/A
117.9	067°	TDZE	N/A
Chan 126		Apt Elev	458

VOR/DME-A

AVI SUQUILLA (P20)

<div><div>V</div><div>NA</div></div>	When local altimeter setting not received, use Blythe altimeter setting and increase all MDA 100 feet.	MISSED APPROACH: Climbing left turn to 5000 direct PKE VORTAC and hold.
--------------------------------------	--	---

AWOS-3PT 132.75	LOS ANGELES CENTER 128.15 285.6	UNICOM 122.725 (CTAF) 0
--------------------	------------------------------------	----------------------------

