

WAAS CH <b>78234</b> <b>W22A</b>	APP CRS <b>224°</b>	Rwy Ldg TDZE Apt Elev	<b>6404</b> <b>7023</b> <b>7038</b>
--	------------------------	-----------------------------	---

RNAV (GPS) RWY 22

FORT BRIDGER (FBR)

RNP APCH.	<div><div><div>NA</div><div>Circling NA to Rwy's 7 and 25. When local altimeter setting not received, use Evanston altimeter setting and increase all MDAs 100 feet, increase LNAV Cats C and D visibility <math>\frac{1}{8}</math> SM, Circling Cat C visibility <math>\frac{1}{4}</math> SM and Cat D visibility <math>\frac{1}{2}</math> SM.</div></div></div>	<div>MISSED APPROACH: Climb to 7500, then climbing right turn to 12000 direct EXILE and hold, continue climb-in-hold to 12000.</div>
-----------	---	--

AWOS-3PT <b>118.8</b>	SALT LAKE CENTER <b>124.35 353.5</b>	UNICOM <b>122.8 (CTAF) 0</b>
--------------------------	---	---------------------------------

