

ILS RWY 17R (SA CAT II)  
OKC WILL ROGERS INTL (OKC)

**MISSED APPROACH:** Climb to 2000 then climbing right turn to 3000 on heading 311° and on PWA VOR/DME R-216 to JESKE INT/PWA 14.5 DME and hold.

ELEV 1296	<b>D</b>	TDZE 1282
-----------	----------	-----------

SA CATEGORY II ILS - SPECIAL AIRCREW  
& AIRCRAFT CERTIFICATION REQUIRED

TDZ/CL Rwy 35R  
MIRL Rwy 13-31  
REIL Rwy 13 and 31  
HIRL Rwy 17L-35R and 17R-35L