

VORTAC ACT <b>115.3</b> Chan <b>100</b>	APP CRS <b>321°</b>	Rwy Ldg <b>5103</b> TDZE <b>516</b> Apt Elev <b>516</b>
---	------------------------	---

VOR/DME RWY 32  
WACO RGNL (ACT)

**V** VDP NA with Mc Gregor Exec altimeter setting. When local altimeter setting  
**A** not received use Mc Gregor Exec altimeter setting and increase all MDA 40  
 ASR feet; increase S-32 Cats C/D visibility  $\frac{1}{8}$  mile and Circling Cat D visibility  $\frac{1}{4}$  mile.

**MISSED APPROACH:** Climb to 3000 direct ACT VORTAC and hold, continue climb-in-hold to 3000.

ATIS <b>123.85</b>	WACO APP CON ★ <b>127.65 227.125</b>	WACO TOWER ★ <b>119.3 (CTAF) 0 257.8</b>	GND CON <b>121.9</b>	UNICOM <b>122.95</b>
-----------------------	---	---	-------------------------	-------------------------