

VOR/DME OTH <b>113.85</b> Chan <b>85(Y)</b>	APP CRS <b>257°</b>	Rwy Ldg TDZE Apt Elev <b>17</b>	<b>N/A</b> <b>N/A</b> <b>17</b>
---	------------------------	--	---------------------------------------

VOR-B

SOUTHWEST OREGON RGNL (OTH)

DME required.	MISSED APPROACH: Climb to 2300 then climbing right turn to 3600 direct OTH VOR/DME and hold.
<div><div></div><div>Circling Rwy 13, 31 NA at night.</div><div></div><div>Rwy 13, 31 helicopter visibility reduction below 1 SM NA.</div></div>	

AWOS-3PT <b>135.075</b>	SEATTLE CENTER <b>127.55 254.35</b>	NORTH BEND TOWER* <b>118.45 (CTAF) 0</b>	GND CON <b>127.1</b>
----------------------------	--	---	-------------------------

