


LOC/DME I-FAI 110.3 Chan 40	APP CRS 203°	Rwy Ldg 11050 TDZE 439 Apt Elev 439	ILS Z or LOC Z Rwy 20R FAIRBANKS INTL (FAI) (PAFA)	
---	------------------------	--	---	--

DME required. DME required for procedure entry.	MALSR 	MISSED APPROACH: Climb to 1100 then climbing left turn to 3000 on FAI VORTAC R-107 to KRNL/FAI VORTAC 13 DME and hold.
---	--	--

ATIS 124.4	FAIRBANKS APP CON 125.35 363.2	FAIRBANKS TOWER 118.3 257.8	GND CON 121.9	CLNC DEL 127.6
----------------------	--	---------------------------------------	-------------------------	--------------------------

