

VOR RWY 20R
KENAI MUNI (ENA) (PAEN)

MALSR

MISSED APPROACH:
Climb to 2200 on ENA
VOR/DME R-192 to DIXIT/ENA
VOR/DME 10 DME and hold.

DME REQUIRED

MSA ENA 2.5 NM
2200
3500
030°
210°

(IAF) TWIGI ENA [8]
R-266

KENAI
117.6 ENA :
Chan 123

2000 NoPT
ENA [8] Arc

FATEL ENA [2.5]
1000 192° (2.5)

TBONE (IF/IAF)
ENA [8]

R-012

ROJAR (IAF)
ENA [8]
R-095

DIXIT ENA [10]

