

VOR/DME VCN <b>115.2</b> Chan <b>99</b>	APP CRS <b>013°</b>	Rwy Idg TDZE Apt Elev <b>N/A</b> <b>N/A</b> <b>150</b>	<div>VOR-B</div> <div>PINE VALLEY (19N)</div>
---	------------------------	---	---

<div>▼</div> Procedure NA at night. Visibility reduction by helicopters NA. <div>▲</div> NA Use Mount Holly altimeter setting, when not received, use Philadelphia Intl altimeter setting and increase MDA 20 feet.	MISSED APPROACH: Climbing right turn to 2100 direct VCN VOR/DME and hold.
--	---

MC GUIRE APP CON <b>126.475 363.8</b>	UNICOM <b>123.0</b> (CTAF) <b>0</b>
--	--

