

LOC/DME I-STF <b>109.9</b> Chan <b>36</b>	APP CRS <b>360°</b>	Rwy Idg <b>5550</b> TDZE <b>326</b> Apt Elev <b>333</b>
---	------------------------	---

## LOC/DME RWY 36

GEORGE M BRYAN (STF)

**V** DME Required. When local altimeter setting not received, use Golden Triangle  
**Δ** NA altimeter setting and increase all MDA 40 feet; increase S-36 Cats C/D visibility  
 ½ mile and Circling Cat C visibility ¼ mile. VDP NA when using Golden Triangle  
 altimeter setting.

**MISSED APPROACH:** Climb to 1000, then climbing left turn to 2400 on IGB VORTAC R-266 to NEEON/IGB 30 DME and hold.

AWOS-3PT <b>118.975</b>	COLUMBUS APP CON ★ <b>135.6 323.275</b>	CLNC DEL <b>126.25</b>	UNICOM <b>122.7</b> (CTAF) <b>0</b>
----------------------------	--	---------------------------	--

