

AIRPORT DIAGRAM

AL-285 (FAA)

NEWARK LIBERTY INTL (EWR)

NEWARK, NEW JERSEY

D-ATIS
 115.7 134.825
 NEWARK TOWER
 118.3 257.6
 GND CON
 121.8
 CLNC DEL
 118.85
 CPDLC




P.A. ADMINISTRATION
 FIRE STATION EQUIPMENT

FBO

AREA 340
 AIRCRAFT
 PARKING

FIELD
 ELEV
 17



NE-2, 11 OCT 2018 to 08 NOV 2018

NE-2, 11 OCT 2018 to 08 NOV 2018

RWY 04L-22R
 PCN 96 R/B/X/T
 D-210, 2D-520, 2D/2D2-1000
 RWY 04R-22L
 PCN 96 R/B/W/T
 D-210, 2D-520, 2D/2D2-1000
 RWY 11-29
 PCN 96 R/B/W/T
 D-210, 2D-520, 2D/2D2-1000

Runway Status Lights In Operation.

ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

**CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
 READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.**

AIRPORT DIAGRAM

NEWARK, NEW JERSEY

NEWARK LIBERTY INTL (EWR)