


AIRPORT DIAGRAM

ATIS
128.55
BROWNSVILLE TOWER★
118.9 239.3
GND CON
121.9

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.



SC-3, 03 JAN 2019 to 31 JAN 2019

SC-3, 03 JAN 2019 to 31 JAN 2019

AIRPORT DIAGRAM