


18312
AIRPORT DIAGRAM

AL-5570 (FAA)

JACKSONVILLE INTL (JAX)
 JACKSONVILLE, FLORIDA

D-ATIS
 125.85
 JACKSONVILLE TOWER
 118.3 317.7
 GND CON
 121.9 348.6
 CLNC DEL
 119.5 290.275

VAR 5.2° N
 JANUARY 2015
 ANNUAL RATE OF CHANGE
 0.1° W



FIELD
 ELEV
 29

SE-3, 03 JAN 2019 to 31 JAN 2019

SE-3, 03 JAN 2019 to 31 JAN 2019

RWY 08-26
 PCN 76 R/B/W/T
 S-120, D-250, 2D-485, 2D/2D2-1005
 RWY 14-32
 PCN 88 R/C/W/T
 S-120, D-250, 2D-480, 2D/2D2-1000

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

81°42'W

81°41'W

AIRPORT DIAGRAM
 18312

JACKSONVILLE, FLORIDA
JACKSONVILLE INTL (JAX)