

AIRPORT DIAGRAM

AL-285 (FAA)

NEWARK LIBERTY INTL (EWR)
NEWARK, NEW JERSEY

D-ATIS
115.7 134.825
NEWARK TOWER
118.3 257.6
GND CON
121.8
CLNC DEL
118.85
RAMP CON
132.45
CPDLC

D

FIELD
ELEV
17

P.A. ADMINISTRATION
FIRE STATION EQUIPMENT

FBO

AREA 340
AIRCRAFT
PARKING

HS 1


HS 2

ELEV 9

ELEV 9

ELEV 10

ELEV 10



NE-2: 12 SEP 2019 to 10 OCT 2019

NE-2: 12 SEP 2019 to 10 OCT 2019

VAR 13.0° W
JANUARY 2015
ANNUAL RATE OF CHANGE
0.0° E

RWY 04L-22R
PCN 96 R/B/X/T
D-210, 2D-520, 2D/2D2-1000
RWY 04R-22L
PCN 96 R/B/W/T
D-210, 2D-520, 2D/2D2-1000
RWY 11-29
PCN 96 R/B/W/T
D-210, 2D-520, 2D/2D2-1000

Runway Status Lights In Operation.

ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

NON MOVEMENT
AREA

74°11'W

74°10'W

AIRPORT DIAGRAM

NEWARK, NEW JERSEY
NEWARK LIBERTY INTL (EWR)