


AIRPORT DIAGRAM

BIRMINGHAM-SHUTTLESWORTH INTL (BHM)
AL-50 (FAA)
BIRMINGHAM, ALABAMA



ATIS
119.4 270.1
BIRMINGHAM TOWER
119.9 317.725
GND CON
121.7 348.6
CLNC DEL
125.675 305.2

RWY 06-24
PCN 65 F/C/X/T
S-175, D-205, 2D-350
RWY 18-36
PCN 45 F/C/X/T
S-75, D-170, 2D-240

JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W

FIELD
ELEV
650

D

SE-4, 16 JUL 2020 to 13 AUG 2020

SE-4, 16 JUL 2020 to 13 AUG 2020

**CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.**

AIRPORT DIAGRAM

BIRMINGHAM, ALABAMA
BIRMINGHAM-SHUTTLESWORTH INTL (BHM)