


AIRPORT DIAGRAM

AL-754 (FAA)

DANIEL K INOUE INTL (HNL) (PHNL)
HONOLULU, HAWAII



PAC, 16 JUL 2020 to 10 SEP 2020

PAC, 16 JUL 2020 to 10 SEP 2020

AIRPORT DIAGRAM

HONOLULU, HAWAII
DANIEL K INOUE INTL (HNL) (PHNL)

**CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.**

ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

JOINT BASE PEARL HARBOR-HICKAM
BASE OPS
HICKAM RAMP ADVISORY
AIR FREIGHT
HAZARDOUS CARGO PAD
CALIBRATION PAD
FIRE STATION
TRAIN ALERT
HAWAII ANG

D-ATIS 127.9 251.15
HONOLULU TOWER 118.1 257.8
GND CON 123.9 273.575 (RWY 08R-26L)
GND CON (RAMP CON) 121.9 348.6
CLINC DEL 121.8
121.4

RWY 04L-22R
PCN 31 F/B/X/T
S-100, D-200, 2D-400,
2D/D1-450, 2D/2D2-850

RWY 04R-22L
PCN 57 F/B/X/T
S-100, D-200, 2D-400,
2D/D1-450, 2D/2D2-850

RWY 08L-26R
PCN 79 R/B/W/T
S-100, D-200, 2T-345,
2D-400, 2D/D1-400,
2D/2D2-780, C5-840

RWY 08R-26L
PCN 98 F/B/X/T
S-80, D-170, 2D-400,
2D/D1-415, 2D/2D2-780, C5-780