

AIRPORT DIAGRAM

AL-384 (FAA)

BOEING FIELD/KING COUNTY INTL (BFI)
SEATTLE, WASHINGTON

ATIS
 127.75
 BOEING TOWER
 118.3 257.8 (RWY 14L-32R)
 120.6 257.8
 (RWYS 14R-32L, ALL IFR)
 GND CON
 121.9
 CLNC DEL
 132.4
D



JANUARY 2020
 ANNUAL RATE OF CHANGE
 0.1° W

TWY ZULU/PPRP

GENERAL AVIATION

HS 1

ELEV 18

134.6°

ELEV 17

TERMINAL

U.S. CUSTOMS RAMP

PRIVATE RAMP

PRIVATE FIRE STATION

BFI FIRE STATION

HS 3

HS 2

GENERAL AVIATION

162

GENERAL AVIATION

MUSEUM

FIELD ELEV 22

MILITARY RAMP

ELEV 21

RWY 14L-32R
 PCN 71 F/A/X/T
 S-120, D-250, 2D-550, 2D/2D2-1109
 RWY 14R-32L
 PCN 90 F/B/W/T
 S-100, D-200, 2D-500, 2D/2D2-800

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
 READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

122°19.0'W

122°18.0'W

AIRPORT DIAGRAM

SEATTLE, WASHINGTON
BOEING FIELD/KING COUNTY INTL (BFI)

NW-1, 10 SEP 2020 to 08 OCT 2020

NW-1, 10 SEP 2020 to 08 OCT 2020