


21168

AIRPORT DIAGRAM

BROWNSVILLE/SOUTH PADRE ISLAND INTL (BRO)
AL-61 (FAA)
BROWNSVILLE, TEXAS

ATIS
128.55
BROWNSVILLE TOWER★
118.9 239.3
GND CON
121.9

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBCK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.



SC-3, 09 SEP 2021 to 07 OCT 2021

SC-3, 09 SEP 2021 to 07 OCT 2021

RWY 13-31
PCN 67 R/D/X/T
S-75, D-170, 2D-240

RWY 18-36
PCN 7 F/C/X/T
S-75, D-144, 2D-150

▲
VAR 3.8° E
JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W

AIRPORT DIAGRAM

21168

BROWNSVILLE, TEXAS
BROWNSVILLE/SOUTH PADRE ISLAND INTL (BRO)