


AIRPORT DIAGRAM

AL-26 (FAA)

SE-4, 22 FEB 2024 to 21 MAR 2024



AIRPORT DIAGRAM

ATLANTA, GEORGIA HARTSFIELD - JACKSON ATLANTA INTL (ATL)

Ramp Frequencies:

Ramp 1	131.45
Ramp 2	131.85
Ramp 3	129.27
Ramp 4	130.07
Ramp 5	129.37
Ramp 6	131.37
Ramp 8	128.97
Ramp 9	131.87
Ramp 6N	Snow and Ice 129.25
Ramp 7	Snow and Ice 131.375
Ramp 20	Snow and Ice 129.25
Ramp 33	Snow and Ice 130.775
Ramp 33	Snow and Ice 129.40
Non Movement Area	131.37


LANDING AIRCRAFT CAN EXPECT TO REMAIN ON TOWER FREQUENCY UNTIL SPECIFICALLY INSTRUCTED TO CONTACT GROUND CONTROL.

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.

READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

JANUARY 2020
ANNUAL RATE OF CHANGE
0.1% W



SE-4, 22 FEB 2024 to 21 MAR 2024