

25107

AIRPORT DIAGRAM

AL-590 (FAA)

IDAHO FALLS RGNL (IDA)

IDAHO FALLS, IDAHO

ATIS
135.325
IDAHO FALLS TOWER ★
118.5 257.8
GND CON
121.7
CLNC DEL
121.7
128.35 239.25 (When Tower Closed)

D

JANUARY 2025
ANNUAL RATE OF CHANGE
0.1° W

ELEV

ELEV
4731

43°31'N

FIRE
STATION

TWR
4822

PASSENGER
TERMINAL

GENERAL AVIATION
PARKING

AIR PATROL

FIELD
ELEV
4744

CORPORATE
PARKING

RWY 03-21
PCR 700 F/B/X/T
S-140, D-175, 2D-270
RWY 17-35
PCR 160 F/D/X/T
S-43, D-58

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

112°05'W

112°04'W

AIRPORT DIAGRAM

25107

IDAHO FALLS, IDAHO
IDAHO FALLS RGNL (IDA)

NW-1, 10 JUL 2025 to 07 AUG 2025

NW-1, 10 JUL 2025 to 07 AUG 2025

AIRPORT DIAGRAM

AL-590 (FAA)

IDAHO FALLS RGNL (IDA)
IDAHO FALLS, IDAHO

ATIS
135.325
IDAHO FALLS TOWER ★
118.5 257.8
GND CON
121.7
CLNC DEL
121.7
128.35 239.25 (When Tower Closed)

D

JANUARY 2025
ANNUAL RATE OF CHANGE
0.1° W

VAR 11.4° E

ELEV
4731ELEV
4731

43°31'N

FIRE
STATION

TWR

PASSENGER
TERMINAL

FBO

GENERAL AVIATION
PARKING

FBO

CIVIL
AIR PATROLFIELD
ELEV
4744CORPORATE
PARKING

RWY 03-21
PCR 700 F/B/X/T
S-140, D-175, 2D-270
RWY 17-35
PCR 160 F/D/X/T
S-43, D-58

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

112°05'W

112°04'W

AIRPORT DIAGRAM

IDAHO FALLS, IDAHO
IDAHO FALLS RGNL (IDA)

25219

NW-1, 07 AUG 2025 to 04 SEP 2025

NW-1, 07 AUG 2025 to 04 SEP 2025