OLD

AIRPORT DIAGRAM

26 34

ATIS
135.575
EAGLE TOWER ★
119.8
GND CON
121.8
CLNC DEL
124.75
D

VAR 9° E

JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W

39°39.0'N

NATIONAL GUARD (HAATS FACILITY)

HANGARS

TWR

FIELD ELEV 6547

BLAST PAD 200 X 200

25

1.0% DOWN

253°

1

A1

A2

A

B

B3

B4

A3

9000 X 150

BLAST PAD 200 X 200

0.9% UP

A4

C1

C2

39°38.5'N

DE-ICE PAD

7

073°

A6

A5

A

C3

A7

ELEV 6461

FIRE STATION

TERMINAL

HS 1

FBO

HANGARS

HANGARS

SRE FACILITY

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

RWY 07-25
PCR 464 F/B/X/T
S-75, D-140, 2S-175, 2D-255

106°55.0'W

106°54.0'W

AL-6403 (FAA)

EAGLE COUNTY RGNL (EGE)
EAGLE, COLORADO

AIRPORT DIAGRAM
26 34
EAGLE COUNTY RGNL (EGE)
EAGLE, COLORADO

NEW

AIRPORT DIAGRAM

26 90

ATIS
135.575
EAGLE TOWER
119.8
GND CON
121.8
CLNC DEL
124.75

D

VAR 9° E

JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W

39°39.0'N

NATIONAL GUARD (HAATS FACILITY)

HANGARS

TWR

FIELD ELEV 6547

BLAST PAD 200 X 200

1.0% DOWN

253°

25

1

A2

A

B3

A3

9000 X 150

A4

C1

C2

39°38.5'N

DE-ICE PAD

BLAST PAD 200 X 200

0.9% UP

7

073°

A6

A7

A5

C3

ELEV 6461

FIRE STATION

TERMINAL

HS 1

FBO

HANGARS

HANGARS

SRE FACILITY

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

RWY 07-25
PCR 464 F/B/X/T
S-75, D-140, 2S-175, 2D-255

106°55.0'W

106°54.0'W

AL-6403 (FAA)

EAGLE COUNTY RGNL (EGE)
EAGLE, COLORADO