AIRPORT DIAGRAM
26134

NIAGARA FALLS, NEW YORK
NIAGARA FALLS INTL (IAG)

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

ATIS
120.8 269.4
NIAGARA TOWER ★
118.5 349.0
GND CON
125.3 275.8
CLNC DEL
119.25 251.1
D

VAR 10° W

JANUARY 1985
ANNUAL RATE OF CHANGE
0.1° W

43°07′N

43°06′N

78°58′W

78°57′W

78°56′W

USAF RESERVE

NEW YORK ANG

USAF RESERVE

FIELD ELEV 592

HS 1

HS 2

BLAST PAD 1000 X 150

ELEV 588

ELEV 588

ELEV 584

100°

280°

9826 X 150

240°

5188 X 150

060°

10

28

06

24

RWY 06-24
PCR 2540 F/B/X/T
S-120, D-250, 2D-462
RWY 10-28
PCR 4110 F/B/X/T
S-120, D-240, 2D-447, 2D/2D2-957

TWR

NEW YORK ARNG

WEST RAMP

GENERAL AVIATION PARKING

TERMINAL

AL-614 (FAA)

NIAGARA FALLS INTL (IAG)
NIAGARA FALLS, NEW YORK