HOUSTON
LEGEND

WEST NORTH EAST

Airports having Control Towers are shown in Blue, all others in Magenta. Consult Airport/Facility Directory (AFD) for details involving airport lighting, navigation aids, and services. All lines are solid unless noted. For additional symbol information refer to the Aeronautical Chart Users' Guide.

AIRPORTS

- Airport, Heliport
- Seaplane Base
- Hard-surfaced runways 1500 ft. to 8069 ft. in length
- Hard-surfaced runways greater than 8069 ft. or with usable length adjacent taxiways
- Open dot within hard-surfaced runway configuration indicates approximate TCH, runway lights, and/or VASI
- All runways hard-surfaced unless otherwise noted. Runways shown to scale.

ADDITIONAL AIRPORT INFORMATION

- Private - "Pvt" - Non-public use having emergency or landmark value.
- Military - Other than joint civil/military airports are identified by abbreviations AFB, NAS, ANG, etc. Some joint civil/military airports are identified in brown.
- ATP - Airport having Airport Traffic Planning document.
- Rotating beacon in operation Sunset to Sunrise
- Rotating beacon not in operation Sunset to Sunrise

OBJECTIONABLE - Airport may adversely affect airspace use.

AIRPORT TRAFFIC SERVICE AND AIRSPACE INFORMATION

Data for communications, navigation, and surface effective below 10,000 ft. MSL are shown on the chart.

- Class B Airspace
- Class C Airspace
- Class D Airspace with operating control tower (see Class D Airspace)
- Class D Airspace with operating control tower (when part time, effective hours may be shown)
- Class E Airspace with floor of 700 ft. AGL unless otherwise indicated
- Class E Airspace with floor of 1200 ft. AGL unless otherwise indicated
- Class E Airspace with floor of 1200 ft. AGL and Differentiates floors of Class E Airspace over 10,000 ft. MSL and Class A Airspace over 18,000 MSL
- Class E Airspace extends at 1200' AGL unless otherwise indicated. Class E Airspace at 700 AGL is not depicted. Class E Airspace are indicated by center line. Airspace boundaries are rounded towards facilities when equitable interpolating.
- Class E Airspace extends upward from a specified altitude to the overlying/underlying Class A, B, C, D, or E airspace. Class E Airspace begins at the surface when not adjacent to an airport with an instrument approach procedure.
- Class G Airspace from the surface to the overlying Class A, B, C, D, or E airspace.
- Special Use Airspace - Prohibited, Restricted, Warning, Alert, MOA, Military Operations Area
- Special Airport Traffic Area
- ADIZ - Air Defense Identification Zone
- DEWIZ - Distant Early Warning Identification Zone
- Military Training Route
- National Security Area
- Flight Restriction Zone (FRZ)
- MTR - Military Training Route

AIRPORT DATA

- Blue indicates FAR 93, Special Air Traffic Rules & Airport Traffic Patterns (public use) — Green indicates private use.
- Tower and Ground Communications Frequency: CT - 118.3 118.6 (ATIS 135.2)
- Airport Elevation - Shown in feet MSL. Unofficial elevations are shown in parentheses.
- Runway Data - Runway dimensions (nearest foot), surface, lighting, runway number, and primary runway's true alignment (nearest 10°).
- Airport Reference Point (ARP) - Latitude and longitude coordinates of the approximate center of airport.
- Control Tower - Airport Traffic Control Tower (ATCT) located on or near the airport.
- Segmented Circle - Pilot reference system of traffic pattern indicators for airports without control towers.
- Rotating Beacon - Clockwise flashing white and green beacon.
- Obstruction - Obstruction to air navigation.
- Runway Lights - Pilot controlled runway lights.
- Wind Cone - Wind direction indicator.
- Landing Fee - Landing fee may be charged.
- Parachute Jumping Area - Parachute jumping activity.
- Glider Operations - Glider operations are frequent.
- Ultralight Activity - Ultralight activity.
- Unmanned Aircraft Activity - Unmanned aircraft activity.

COMMUNICATION BOXES

- Control Tower
- Automated Weather Observing System (AWOS-3)
- Crosswind runways
- Automated Surface Observing System (ASOS)
- Limited operation
- Remotely Monitored
- Voice

Shows one-time activation Right Rotation Beacon (RBN). Frequencies 126.0, 135.6, 255.0 and 255.4. Everyday, 1315-1345 Z and 2015-2045 are available at Houston Executive Airport (HQZ) and Houston Southwest Airport (AXH).

Shows one-time activation Airport Advisory Service, see A/FD.

Receive only

Shows that the box are rendered to handoff (dbs. Other PCE frequencies providing Flight Service Station (FSS) radio services are shown by altitude and address. Consult Airport/Facility Directory for more information.

RADIO AIDS TO NAVIGATION

- VHF OMNI RANGE (VOR)
- VOR-DME
- VORTAC
- VOR with TACAN, no FSS, no DME, NDB, etc.
- Non-Directional Radio Beacon (NDB)
- NDB - DME

OBSTRUCTIONS

- 1000 ft and higher AGL
- Below 1000 ft AGL
- Wind Turbine
- Wind Turbine Farm
- Elevation of the top above mean sea level. Unlighted obstructions are shown when considered significant. Obstruction elevation unverified unless followed by an asterisk. Consult publication for full depictions.
- Group Obstruction
- Obstruction with high-intensity white strobe lights (ASR-DAY)

MISCELLANEOUS

- Parachute Jumping Area (Unverified Parachute Jumping Frequency)
- Space Launch Activity and Reentry Area(s)
- VRVXZ
- 9999 (PPTO)
- VFR Waypoints (Five-Letter Identifier)
- Name Light

TOPOGRAPHIC INFORMATION

- Shoreline
- Aerial Cable
- 8197 Elevation Above Sea Level
- Mountain Peak
- 11853 (Elevation of Peak)
- Arrow indicates the direction of concentrated slope or direction of flight and base elevation of the next charted contour, relief or obstacle. Hazardous flight conditions may exist within and near mountain passes.

HOUSTON SECTIONAL

SECTIONAL AERONAUTICAL CHART SCALE 1:500,000

Federal Aviation Administration

97TH EDITION EFFECTIVE 0901Z **3 MAR 2016**
TO 0901Z **15 SEP 2016**

Includes airspace amendments effective **4 FEB 2016**
and all other aeronautical data received by **7 JAN 2016**

Information on this chart will change; consolidated updates of chart changes are available every 56 days in the AIRPORT/FACILITY DIRECTORY Chart Bulletin section online at http://faa.gov/ajv/ats/. Also consult appropriate NOTICES TO AIRMEN (NOTAMs) and other FLIGHT INFORMATION PUBLICATIONS (FLIPs) for the latest changes.

PUBLISHED IN ACCORDANCE WITH INTERAGENCY AIR CARTOGRAPHIC COMMITTEE SPECIFICATIONS AND AGREEMENTS, APPROVED BY DEPARTMENT OF DEFENSE / FEDERAL AVIATION ADMINISTRATION.

Warning: Refer to current foreign charts and flight information publications for information within foreign airspace.

FAA Product ID: SHOU

NSN 7641011410174

Item Name: SECSHOUSTON

Item Serial: 16063

PLOTTING DIRECT ROUTE ON NORTH/SOUTH SIDE

There are approximately 10 minutes of latitude overlap between the north and south sides of each NORTH/SOUTH chart. To plot a direct route between the north and south charts first locate two pair of corresponding latitude tick marks, one pair on each side of the chart and follow the steps below:

STEP 1 - Draw a straight line between each pair of corresponding latitude tick marks on each side of the chart just to the left or right of the area where the route is to be plotted.

STEP 2 - Decide which side of the chart has the departure or destination point closer to the edge of the chart. Place the straight edge of a piece of paper along the MATCH LINE this paper should be colinear with the MATCH LINE on the side of the chart.

STEP 3 - Slide the paper sideways left or right so that a side edge of the paper aligns with the departure or destination point. Mark this point as POINT A on edge of the paper where it meets that MATCH LINE.

STEP 4 - Without moving the paper, on the same edge as MARK A, extend a short line on the chart past the MATCH LINE and label it LINE A. Label the MATCH LINE out to the edge of the chart. Make this LINE 1.

STEP 5 - Turn the chart over and transfer the end of LINE B to the other side, and extend it straight to a MATCH LINE. Label this LINE 2.

STEP 6 - Take the sheet of paper with MARK A on it and place the edge of the paper along LINE 2 and the MATCH LINE and side down with LINE B with the bulk of the sheet extending off of the chart. Place a MARK C on the edge of the paper at the point POINT B.

STEP 7 - Where your plot line crosses the MATCH LINE make a MARK C. Extend a line straight from that mark to the edge of the chart.

STEP 8 - Turn the chart over and transfer MARK C to that side and extend it to the MATCH LINE. Pick a line from MARK C to the destination. (Figure 3)

CONTROL TOWER FREQUENCIES ON HOUSTON SECTIONAL CHART

Airports with control towers are indicated on the face of the chart by the letters CT followed by the primary VHF band control frequency (see. Information for each tower is listed in the table below. Operational hours are local time. The primary VHF and UHF band control frequencies are listed. An asterisk (*) indicates the part-time tower frequency is revealed in a subscribed full-time TSE for use as directed by the controlling agency during the hours the tower is not in operation. Consult Airport/Facility Directory.

Automatic Terminal Information Service (ATIS) broadcast frequencies shown on the face of the chart are primary vertical VHF/UHF frequencies. All ATIS frequencies are listed in the table below. ATIS operational hours may differ from tower operational hours.

ATIS/AWOS/ASOS updated hourly except when weather conditions are changeable.

"ACTIVE" indicates Monday through Friday.

"VARIES" indicates varies.

CONTROL TOWER	OPERATES	TWR FREQ	GND CON	ATIS	ASR/PAR
ACADIANA INTL	0600-2100	120.9	121.7		
ADDISON, TX	CONTINUOUS	127.35 340.4	121.9 372.3		ASR/PAR
ALEXANDRIA INTL	0600-2200	118.3	121.9		ASR
BROOKS AAF	1400-2200	124.2	124.65	126.5	
CORPUS INTL	0600-2200	124.2 380.4	121.65 372.8	128.5	ASR
ELLINGTON	0700-2200	123.6	121.9	118.3	
GALVESTON	CONTINUOUS	120.05 257.2	121.8	125.0 257.8	
GEORGE BUSH INTCONTINENTAL	CONTINUOUS	135.05 255.2 (RAPCO) 379.1 (DEPCO) 341.9* 269.1* (RAPCO) 379.1 (DEPCO) 341.9*	118.375 (RAPCO) 121.9 (DEPCO) 396.5M & 269.1M	124.55	120.5 257.4
HOBBY	CONTINUOUS	119.7 252.2	121.8	124.4	
HOOKS MEM	0700-2200	119.4 342.4 (1315-2245Z)	121.8 229.0	128.375	
HOUMA-TERREBONNE	0600-1900	120.2 396.0	121.8	135.05	
LAFAYETTE REGIONAL	0600-2200	118.7	121.8	124.05	ASR
LAKEFIELD BEAUREGARD	0600-2200	120.4	121.8	118.55	ASR
LAKE CHARLES REGIONAL	0600-2200	120.7 257.8	121.8	118.75	ASR
LONGVIEW GTR	0700-2200	118.3	121.8	124.35	
PEAR, HAF	1200-1100 HOL	123.95	121.8 339.25	134.65 382.2	AIRFAC
ROOSEVELT, HF, DAVIDSON	1200-0400	120.05	118.425		
SUGAR LAND INTL	0600-2200	118.6	121.8	124.0	
VICTORIA REGIONAL	0700-2200	118.575 257.95	121.925 239.25	119.025	

CLASS B, CLASS C, TRSA, AND SELECTED APPROACH CONTROL FREQUENCIES

FACILITY	FREQUENCIES	SERVICE AVAILABILITY
HOUSTON CLASS B	120.2 382.4 SE 118.325 (HOUSTON APP) 124.0 337.2 351 (HOUSTON APP) 126.4 (HOUSTON APP) 269.1 (HOUSTON APP)	COMPASS/IFR
BAYOU ROUGE CLASS C	118.3 379.4 (HOUSTON APP) 269.1 (HOUSTON APP)	CCF CLASS D
HOBBY/EC CLASS C	119.7 252.2 (HOUSTON APP) 124.0 337.2 (HOUSTON APP) 126.4 (HOUSTON APP) 269.1 (HOUSTON APP)	CCF CLASS D
LAKE CHARLES TRSA	118.75 (HOUSTON APP) 120.7 257.8 (HOUSTON APP) 269.1 (HOUSTON APP)	CCF CLASS D
PEAR, HAF	123.95 339.25 (HOUSTON APP) 269.1 (HOUSTON APP)	AIRFAC
ROOSEVELT, HF, DAVIDSON	120.05 (HOUSTON APP) 269.1 (HOUSTON APP)	CCF CLASS D
SUGAR LAND INTL	118.6 (HOUSTON APP) 269.1 (HOUSTON APP)	CCF CLASS D
VICTORIA REGIONAL	118.575 257.95 (HOUSTON APP) 269.1 (HOUSTON APP)	COMPASS/IFR

SPECIAL USE AIRSPACE ON HOUSTON SECTIONAL CHART

Unless otherwise noted altitudes are MSL. Times are local.
"H" and "Night Thru Dawn" are excluded.
H – Flight hour
NOTAM – Notice to ground communities. Consult flight Service for information.

* Other times by NOTAM.
Time of use not shown is illustrated.
Refer to Date (DAILY) and NOTAM systems. Use of this term is not limited to activities under the DoD NOTAM system.

U.S. P-PROHIBITED, R-RESTRICTED, W-WARNING, A-ALERT, MOA-MILITARY OPERATIONS AREA

NUMBER	ALTITUDE	TIME OF USE	CONTROLLING AGENCY/ CONTACT FACILITY	FREQUENCIES
R 5801 A	SFC-FL180	0600-2200	HOUSTON CNTR	
R 5801 B	12,000 MSL-FL180	0600-2200	HOUSTON CNTR	
R 5802 A	SFC-FL180	CONTINUOUS	HOUSTON CNTR	
R 5802 B	12,000 MSL-FL180	CONTINUOUS	HOUSTON CNTR	
R 5803 A	SFC-FL180	0700-0400	HOUSTON CNTR	
R 5803 B	12,000 MSL-FL180	0700-0400	HOUSTON CNTR	
R 5804 A	SFC-FL240	0700-0400	HOUSTON CNTR	
R 5804 B	12,000 MSL-FL240	0700-0400	HOUSTON CNTR	
R 5805 A	SFC-FL240	0600-0100	HOUSTON CNTR	
R 5805 B	8000 MSL-FL240	0600-0100	HOUSTON CNTR	
R 5806 A	SFC-FL240	0600-0100	HOUSTON CNTR	
R 5806 B	8000 MSL-FL240	0600-0100	HOUSTON CNTR	
R 5807 A	SFC-FL180	0600-0100	HOUSTON CNTR	
R 5807 B	8000 MSL-FL180	0600-0100	HOUSTON CNTR	
R 5808 A	SFC-FL180	0600-0100	HOUSTON CNTR	
R 5808 B	8000 MSL-FL180	0600-0100	HOUSTON CNTR	
R 5809 A	SFC-FL180	0600-0100	HOUSTON CNTR	
R 5809 B	8000 MSL-FL180	0600-0100	HOUSTON CNTR	
R