PILOTS

MEMPHIS

NORTH

LEGEND

Airports having Control Towers are shown in Blue, all others in Magenta. Consult Chart Supplement for details including airport lighting, navigation aids, and services. For the additional symbol information refer to the Chart Users Guide.

AIRPORTS

- Other than hard-surfaced runway
- Hard-surfaced runway 1500 ft. to 8999 ft. in length
- Hard-surfaced runway greater than 8999 ft. or hard-surfaced runway with usable length unknown
- Sand dirt (other hard-surfaced runway configuration indicators approximate CNPL, dimensions unknown)
- Abandoned hard-surfaced runways, runway(s) are shown as they appear on the ground, but are not labeled as such.
- Seaplane Base

ADDITIONAL AIRPORT INFORMATION

- Private (PVT) - Not available for use by the general public
- Military - Other than joint use (mil), landing rights (LRTS), or emergency only (EMERG) airports may be restricted.
- Landmark
- Abandoned Airport
- Heliport
- Glider Operations
- Balloon Operations
- Parachute Jumping Activity

Fuel - Available 8AM (Fri-Fri 10:00 A.M. or 4:00 P.M. daycard) to 5PM unless otherwise indicated. Self-service or 24 hour fuel availability may be limited to certain types of aircraft, with hard-surfaced runways greater than 8069 ft.

Rotating airport beacon in operation Sunset to Sunrise

OBJECTIONABLE - Airport has obstacle(s) penetrating an obstacle clearance surface.

AIRPORT TRAFFIC CONTROL SERVICE

AIRSPACE INFORMATION

Only the controlled and manned airspace associated with the airports are shown in this chart.

Key to Airspace

- Class B Airspace Blocks (↓ Floor / ↑ Ceiling)
- Class C Airspace
- Class D Airspace (Operational hours of Part-Time surface area Class D airspace are published in the Chart Supplement)
- Class E Airspace with floor 700 feet or 1200 feet above the surface (CLASS E)
- Class E Airspace with floor 1200 feet or more above the surface (CLASS E)
- Class E Airspace with floor at the surface designated for an airport (CLASS E)
- Class E Airspace with floor at the surface designated for an airport (CLASS E)
- Differentiation Boxes of Class E Airspace with floor 700 feet above surface
- Class E Airspace with floor 1200 feet above surface
- Class E Airspace with floor at the surface designated for an airport
- Class E Airspace not shown Federal Airway Intersection - Arrows are directed towards the controlling facility
- Low Altitude Airway
- Total Mileage of Federal Airways between VOR/DME facilities (Mileage is not provided for control 1nc.)
- Class B Airspace Floors & Ceilings (MSL)
- Class C Airspace Floors & Ceilings (MSL)
- Class D Airspace Floors & Ceilings (MSL)
- Class E Airspace Floors & Ceilings (MSL)
- Military Operations Area (MOA)
- Warning Area (WARNING)
- Alert Area (ALERT)
- Prohibited Area (PROHIBITED)
- Restricted Area (RESTRICTED)
- Military Training Route (MTR) - Instrument (IR) - Visual (VR)

COMMUNICATION BOXES

RADIO AIDS TO NAVIGATION

- VHF OMNI RANGE (VOR)
- VOR/DME
- VORTAC
- TACAN
- Non-Directional Radio Beacon (NDB)
- NDB / DME

OBSTRUCTIONS

MISCELLANEOUS

- Parachute Jumping Area (See Chart Supplement)
- Glider Operations
- Hang Gliding Activity
- Ultralight Activity
- Balloon Operations
- Control Zone
- Aerial Refueling Track
- Aerial Refueling Area
- Warning Light

TOPOGRAPHIC INFORMATION

- Power Transmission Line
- Pipeline
- Railroad
- Interstate Highway
- U.S. Highway
- State Highway
- Mountain Pass
- Elevations of Peaks, Obstructions, Spot Elevations and Contours are in feet above mean sea level (MSL). Shaded contours show relief characteristics. Drain and indicate a recommended clearance above the highest MSL figure in the area within and near mountain passes.

AIRPORT DATA

Box indicates ATIS, ASOS, AWOS, or other automatic weather reporting frequency. Rotate to Airport Traffic Control Tower (ATCT) frequency. CT - 118.1 ⇔ 6/10, 123.8 Rotates (public use, ATCT part time) CTAF 123.8 UNICOM 122.95 PDD - Flight Service Station. P-56 - Prohibited area. Civil aircraft VFR flight is prohibited. CT - 118.1 - Control Tower (CT) - Airport Traffic Control Tower. A - Star indicates operation part-time. See Inset Procedures or Chart Supplement for details. Follow the Common Traffic Advisory Frequency (CTAF). ATIS 133.9 - Automatic Terminal Information Service. ASOS/AWOS - 135.25 - Automated Surface Observing System / Automated Weather Observing System where full time ATIS not available. UNICOM - Nonfederal communication facility. UNICOM - Aeronautical advisory station. Flight Watch - En route weather advisory broadcast by Flight Service Stations (FSS) on a frequency of 122.0 MHz (usually assigned to the closest VOR to the station providing the service). Flight Service Station (FSS) - Air traffic facility which provides pilot briefing, en route communications and VFR search and rescue services, assigns discrete transponder codes, receives and processes IFR flight plans, and monitors navaids. Limited Combined Station Procedure - Indicates FSS operates less than 24 hours daily. Hours of operation are shown on the chart. Pilots should contact the FSS for the availability of specific services. Local Airport Advisory - Provides advisory service to pilots at airports without operating control towers. Remote Communications Outlet - Unmanned communications facility remotely controlled by FSS personnel. Receive only. Frequencies shown like this are not assigned to the primary FSS but are assigned by Direction Finding (DF) to extend the communications coverage of the primary FSS.

CONTROL TOWER FREQUENCIES ON MEMPHIS SECTIONAL CHART

Airports with operating control towers are listed in the Control Tower Frequency (CTAF), Automatic Terminal Information Service (ATIS), Ground Control (GC), Local Control (LC), Departure Control (DEP), and Clearance Delivery (CD) frequency data block. Numbers in bold face (**118.3**) are Tower frequencies. Frequencies in normal face (124.4) are Ground Control frequencies. Frequencies in italics (*121.9*) are Clearance Delivery frequencies. Frequencies in bold face italics (***119.1***) are Local Control frequencies. Automatic Terminal Information Service (ATIS) frequencies shown on the face of the chart are primary arrival ATIS/AWOS/ASOS frequencies. All ATIS frequencies are listed in the table below. ATIS operational hours may differ from tower operational hours.

"ATIS" indicates Arrival ATIS broadcast available.
"ATIS-D" indicates Departure ATIS broadcast available.
"ATIS-A/D" indicates Arrival/Departure ATIS broadcast available.

CONTROL TOWER	OPERATES	TWR FREQ	GND CON	ATIS	ASOS/FSS
SARDIS/E. JAN	COMPASS/S	126.0 378.3	121.9 *355.4*	120.425	ASE
BIG WHITE HOUSE/ CARUTHERSVILLE MEMPHIS	COMPASS/S	118.7 *337.9*	121.9 *389.8*	135.65	ASE
COLUMBUS AFB	OPEN 1500Z-0400Z/M-F 1500Z-2100Z/SA	**134.05** *379.775*	121.9 *275.8*	113.2 *275.3*	
DEMOPOLIS	0900-2300	**119.3** *327.05*	121.9	119.05	ASE
HOT SPRINGS INTNL	0600-2300	**118.3** *269.55*	121.9	119.45	ASE
LITTLE ROCK AFB	OPEN 1500Z-0400Z	**120.9** *269.55*	121.9 *257.8*	126.325	
LONGVIEW/E. MCCRAIN	OPEN 1500Z-0400Z	**119.8** *339.8*	121.9 *268.8*		
MEMPHIS INTL	OPEN 1500Z-0400Z	**118.7** *257.8*	121.9 *340.2*	121.65	ASE
MEMPHIS/DOWNTOWN	0600-2300	**120.9** *269.5*	121.9 *346.2*	127.55	ASE
MEMPHIS/PINK PALMS	0600-2300	**120.9** *269.5*	121.9 *346.2*	127.55	ASE
MPV	0400-0700 1200-2100	123.075 *327.8*	121.9 *346.2*	134.625 *257.675*	
OTIS ROCK AFB	OPEN 1500Z-0400Z/M-F 1500Z-2100Z/SA	**120.6** *349.075*	118.9 *377.8*	118.175 *320.1*	
SE ARKANSAS REGL	COMPASS/S	118.3 *257.8*	121.9 *346.2*	120.05	ASE
WEARS FLD	COMPASS/S	118.7 (BKN 9,000 - 12,000) *257.8* (BKN 9,000 - 12,000)	121.9 (BKN 9,000 - 12,000) *346.2* (BKN 9,000 - 12,000)	127.75	
WESTOVER AHP (MC CAIN)	OPEN 1500Z-0400Z/M-F 1500Z-2100Z/SA	**120.1** *269.1* 135.4 *PPR*	118.4	255.525	ASE/FAM
WILKINSON REGL	0900-0200Z/ M-F 0700-0200Z SA-SU 0600-1700Z SEP-APR	**120.1** *269.1* 135.4 *PPR*	118.4	124.375	
WILLIAMS REGL	0700-0300	**119.2** *327.8*	121.9	133.05	ASE
LAKE MARVEL	0700-0300	**119.2** *327.8*	121.9	133.05	ASE
WILLIAMSON-SUGGS	0700-0300	**119.2** *327.8*	121.9	133.05	ASE
WINDSHOR REGL	COMPASS/S	123.6 *256.775*	121.9 *256.775*	136.65	ASE
WINNSBORO	1400-2200	**122.8**			
WYNNE/ERIC NEBE	1400-2200	**122.8**			
YAZOO INTL	0600-2300	**119.3** *255.875*	121.9 *340.975*		
YORK	0600-2300	**119.3** *255.875*	121.9 *340.975*		ASE

CLASS B, CLASS C, TRSA, AND SELECTED APPROACH CONTROL FREQUENCIES

FACILITY	FREQUENCIES	SERVICE AVAILABILITY
MEMPHIS CLASS B	124.8 258.2 (DAP 0700-1900Z) 124.8 (DAP 1900-0700Z)	COMPASS/S
COLUMBUS AFB CLASS C	119.05 *255.8* (0700-0300Z) 119.05 *255.8* (0300-0700Z) 134.675 *255.8* (DAP VMC) 119.05 *255.8* (DAP IMC)	0700-0300Z (M-SA) 0300-0700Z (M-SA) (120.45) (SU) 0700-0300Z (M-SA)
HAZLEHURST CLASS C	119.2 *327.8* (0800-2200Z) 123.7 (2200-0800Z) *327.8* (0800-2200Z)	0800-2200Z (M-SA) (SU)
LITTLE ROCK CLASS C	119.3 *255.875* (DAP) 118.9 *377.8* (DAP)	COMPASS/S
SHREVEPORT CLASS C	119.7 *339.65* (DAP) 124.2 *339.65* (DAP)	COMPASS/S
TUPELO CLASS C	120.7 *269.55* (DAP) 124.2 (DAP)	1200-0300Z
LONGVIEW TRSA	124.075 (1200-0400Z) *257.8* (0400-1200Z) 124.075 (1200-0400Z) *346.2* (0400-1200Z)	0400-2200
MONROE TRSA	124.3 (0400-0400Z) *257.8* (0400-0400Z) 124.3 (0400-0400Z) *346.2* (0400-0400Z)	0400-2200
OTIS ROCK AFB	124.1 *349.075* (0400-0400Z) 124.1 *377.8* (0400-0400Z)	COMPASS/S
WINNSBORO (MC CAIN)	119.1 *269.1* (0700-0300Z) 119.1 *340.2* (0700-0300Z)	0700-0300
WILLIAMS (VGT)	119.2 *327.8* (0800-2200Z)	0700-2300

SPECIAL USE AIRSPACE ON MEMPHIS SECTIONAL CHART

Unless otherwise noted altitudes are MSL. Times are local. "H24" - Continuously. "NOTAM" - Notice to Airmen Publication is issued every 56 days. "SS-SR" - Sunset to Sunrise. "HOL" - Holidays. "WD" - Weekdays. "WE" - Weekends. NO ACTIVITY MAY EXIST WITHIN A PUBLISHED ACTIVE AREA. NOTICES TO AIRMEN (NOTAMs) and other FLIGHT INFORMATION PUBLICATIONS (FLIPs) list the latest changes.

U.S. PROHIBITED, RESTRICTED, WARNING, ALERT, MOA MILITARY OPERATIONS AREA

NUMBER	ALTITUDE	TIME OF USE	CONTROLLING AGENCY / COMMUNICATIONS FREQUENCIES
R-2401, A, B, C	SFC-B2,000	SR-SS	MEMPHIS CNTR
R-2402, A	SFC-B5,000	H24	MEMPHIS CNTR
R-2402, B	5,000 TO B17,000	H24	MEMPHIS CNTR
R-2402, C	5,000 TO B17,000	SR-SS	MEMPHIS CNTR
R-2404, A	SFC-11,000	0700-1900 M-F 0700-1600 SA	MEMPHIS CNTR
R-2404, B	1,000 TO B17,000	SR-SS	MEMPHIS CNTR
R-2404, C	11,000 TO B17,000	0700-1900 M-F 0700-1600 SA	MEMPHIS CNTR
R-2405	SFC-B5,000	H24	MEMPHIS CNTR
R-2406	SFC-B5,000	H24	MEMPHIS CNTR
R-2407	SFC-B5,000	H24	MEMPHIS CNTR
R-2408	SFC-B5,000	H24	MEMPHIS CNTR
R-2409	SFC-B5,000	H24	MEMPHIS CNTR
R-2410	SFC-B5,000	H24	MEMPHIS CNTR
R-2411	SFC-B5,000	H24	MEMPHIS CNTR
R-2412	SFC-B5,000	H24	MEMPHIS CNTR
R-2413	SFC-B5,000	H24	MEMPHIS CNTR
R-2414	SFC-B5,000	H24	MEMPHIS CNTR
R-2415	SFC-B5,000	H24	MEMPHIS CNTR
R-2416	SFC-B5,000	H24	MEMPHIS CNTR
R-2417	SFC-B5,000	H24	MEMPHIS CNTR
R-2418	SFC-B5,000	H24	MEMPHIS CNTR
R-2419	SFC-B5,000	H24	MEMPHIS CNTR
R-2420	SFC-B5,000	H24	MEMPHIS CNTR
R-2421	SFC-B5,000	H24	MEMPHIS CNTR
R-2422	SFC-B5,000	H24	MEMPHIS CNTR
R-2423	SFC-B5,000	H24	MEMPHIS CNTR
R-2424	SFC-B5,000	H24	MEMPHIS CNTR
R-2425	SFC-B5,000	H24	MEMPHIS CNTR
R-2426	SFC-B5,000	H24	MEMPHIS CNTR
R-2427	SFC-B5,000	H24	MEMPHIS CNTR
R-2428	SFC-B5,000	H24	MEMPHIS CNTR
R-2429	SFC-B5,000	H24	MEMPHIS CNTR
R-2430	SFC-B5,000	H24	MEMPHIS CNTR
R-2431	SFC-B5,000	H24	MEMPHIS CNTR
R-2432	SFC-B5,000	H24	MEMPHIS CNTR
R-2433	SFC-B5,000	H24	MEMPHIS CNTR
R-2434	SFC-B5,000	H24	MEMPHIS CNTR
R-2435	SFC-B5,000	H24	MEMPHIS CNTR
R-2436	SFC-B5,000	H24	MEMPHIS CNTR
R-2437	SFC-B5,000	H24	MEMPHIS CNTR
R-2438	SFC-B5,000	H24	MEMPHIS CNTR
R-2439	SFC-B5,000	H24	MEMPHIS CNTR
R-2440	SFC-B5,000	H24	MEMPHIS CNTR
R-2441	SFC-B5,000	H24	MEMPHIS CNTR
R-2442	SFC-B5,000	H24	MEMPHIS CNTR
R-2443	SFC-B5,000	H24	MEMPHIS CNTR
R-2444	SFC-B5,000	H24	MEMPHIS CNTR
R-2445	SFC-B5,000	H24	MEMPHIS CNTR
R-2446	SFC-B5,000	H24	MEMPHIS CNTR
R-2447	SFC-B5,000	H24	MEMPHIS CNTR
R-2448	SFC-B5,000	H24	MEMPHIS CNTR
R-2449	SFC-B5,000	H24	MEMPHIS CNTR
R-2450	SFC-B5,000	H24	MEMPHIS CNTR
R-2451	SFC-B5,000	H24	MEMPHIS CNTR
R-2452	SFC-B5,000	H24	MEMPHIS CNTR
R-2453	SFC-B5,000	H24	MEMPHIS CNTR
R-2454	SFC-B5,000	H24	MEMPHIS CNTR
R-2455	SFC-B5,000	H24	MEMPHIS CNTR
R-2456	SFC-B5,000	H24	MEMPHIS CNTR
R-2457	SFC-B5,000	H24	MEMPHIS CNTR
R-2458	SFC-B5,000	H24	MEMPHIS CNTR
R-2459	SFC-B5,000	H24	MEMPHIS CNTR
R-2460	SFC-B5,000	H24	MEMPHIS CNTR
R-2461	SFC-B5,000	H24	MEMPHIS CNTR
R-2462	SFC-B5,000	H24	MEMPHIS CNTR
R-2463	SFC-B5,000	H24	MEMPHIS CNTR
R-2464	SFC-B5,000	H24	MEMPHIS CNTR
R-2465	SFC-B5,000	H24	MEMPHIS CNTR
R-2466	SFC-B5,000	H24	MEMPHIS CNTR
R-2467	SFC-B5,000	H24	MEMPHIS CNTR
R-2468	SFC-B5,000	H24	MEMPHIS CNTR
R-2469	SFC-B5,000	H24	MEMPHIS CNTR
R-2470	SFC-B5,000	H24	MEMPHIS CNTR
R-2471	SFC-B5,000	H24	MEMPHIS CNTR
R-2472	SFC-B5,000	H24	MEMPHIS CNTR
R-2473	SFC-B5,000	H24	MEMPHIS CNTR
R-2474	SFC-B5,000	H24	MEMPHIS CNTR
R-2475	SFC-B5,000	H24	MEMPHIS CNTR
R-2476	SFC-B5,000	H24	MEMPHIS CNTR
R-2477	SFC-B5,000	H24	MEMPHIS CNTR
R-2478	SFC-B5,000	H24	MEMPHIS CNTR
R-2479	SFC-B5,000	H24	MEMPHIS CNTR
R-2480	SFC-B5,000	H24	MEMPHIS CNTR
R-2481	SFC-B5,000	H24	MEMPHIS CNTR
R-2482	SFC-B5,000	H24	MEMPHIS CNTR
R-2483	SFC-B5,000	H24	MEMPHIS CNTR
R-2484	SFC-B5,000	H24	MEMPHIS CNTR
R-2485	SFC-B5,000	H24	MEMPHIS CNTR
R-2486	SFC-B5,000	H24	MEMPHIS CNTR
R-2487	SFC-B5,000	H24	MEMPHIS CNTR
R-2488	SFC-B5,000	H24	MEMPHIS CNTR
R-2489	SFC-B5,000	H24	MEMPHIS CNTR
R-2490	SFC-B5,000	H24	MEMPHIS CNTR
R-2491	SFC-B5,000	H24	MEMPHIS CNTR
R-2492	SFC-B5,000	H24	MEMPHIS CNTR
R-2493	SFC-B5,000	H24	MEMPHIS CNTR
R-2494	SFC-B5,000	H24	MEMPHIS CNTR
R-2495	SFC-B5,000	H24	MEMPHIS CNTR
R-2496	SFC-B5,000	H24	MEMPHIS CNTR
R-2497	SFC-B5,000	H24	MEMPHIS CNTR
R-2498	SFC-B5,000	H24	MEMPHIS CNTR
R-2499	SFC-B5,000	H24	MEMPHIS CNTR
R-2500	SFC-B5,000	H24	MEMPHIS CNTR

MOA NAME	ALTITUDE*	TIME OF USE	CONTROLLING AGENCY / COMMUNICATIONS FREQUENCIES
ARKANSAS MOA	7000	SR-SS WD	LITTLE ROCK APP 119.05 *255.8*
ARMY LOW	100 AGL TO, BUT NOT INCL 1,500 MSL	SR-SS WD/ATIN	FORT WORTH CNTR 119.05 *346.35*
BIRCHHEAD MOA	500 AGL TO, BUT NOT INCL 5,000 MSL	SR-SS WD/ATIN	MEMPHIS CNTR 119.05 *346.35*
BRIARWOOD MOA	10000	0700-0300	ATLANTA CNTR
BRIARWOOD A	8000 TO, BUT NOT INCL 10000	0700-0300	ATLANTA CNTR
CAMDEN MOA	500 AGL TO, BUT NOT INCL 5000 MSL	0700-0300	ATLANTA CNTR
COLUMBUS 1, 2, 3	8000	SR-SS WD/ATIN	MEMPHIS CNTR
COLUMBUS 4	10,000	SR-SS WD/ATIN	MEMPHIS CNTR
CROSSVILLE	7000	SR-SS WD/ATIN	MEMPHIS CNTR 134.05 *346.35*
HOG LOW SOUTH MOA	4000	0300-0500 WD/ATIN	HOUSTON CNTR 132.45 *340.2*
HOG HIGH SOUTH MOA	4000	0300-0500 WD/ATIN	HOUSTON CNTR 132.45 *340.2*
HOG LOW NORTH MOA	4000	0300-0500 WD/ATIN	MEMPHIS CNTR 134.7 *327.0*
HOG HIGH NORTH MOA	500 AGL TO, BUT NOT INCL 4000 MSL	0300-0500 WD/ATIN	MEMPHIS CNTR 134.7 *327.0*
HOUSTON MOA	8000 TO, BUT NOT INCL 10000 MSL	0900-2300 WD/ATIN	HOUSTON CNTR
JENA MOA	8000	SR-SS WD/ATIN	MEMPHIS CNTR
JENA MOA A	7000 TO, BUT NOT INCL 8000 MSL	SR-SS WD/ATIN	MEMPHIS CNTR
JENA MOA B	7000 TO, BUT NOT INCL 8000 MSL	SR-SS WD/ATIN	MEMPHIS CNTR
LAKE VILLAGE MOA	7000	SR-SS WD/ATIN	MEMPHIS CNTR
LAKE VILLAGE A	7000 TO, BUT NOT INCL 8000 MSL	SR-SS WD/ATIN	MEMPHIS CNTR
LAKE VILLAGE B	7000 TO, BUT NOT INCL 8000 MSL	SR-SS WD/ATIN	MEMPHIS CNTR
MERIDIAN 1 WEST MOA	7000	SR-SS WD/ATIN	MEMPHIS CNTR
MERIDIAN 2 EAST MOA	7000	SR-SS WD/ATIN	MEMPHIS CNTR
MERIDIAN 2 WEST MOA	7000	SR-SS WD/ATIN	MEMPHIS CNTR
PINE HILL WEST MOA	7000	SR-SS WD/ATIN	MEMPHIS CNTR
RIVERS MOA	7000	SR-SS WD/ATIN	MEMPHIS CNTR
SHIRLEY A MOA	7000	SR-SS WD/ATIN	MEMPHIS CNTR
SHIRLEY B MOA	7000	SR-SS WD/ATIN	MEMPHIS CNTR
SHIRLEY C MOA	7000	SR-SS WD/ATIN	MEMPHIS CNTR
TUNICA MOA	7000	SR-SS WD/ATIN	MEMPHIS CNTR
TUNICA A	7000 TO, BUT NOT INCL 8000 MSL	SR-SS WD/ATIN	MEMPHIS CNTR
TUNICA B	7000 TO, BUT NOT INCL 8000 MSL	SR-SS WD/ATIN	MEMPHIS CNTR
WOODRUFF MOA	7000	SR-SS WD/ATIN	MEMPHIS CNTR
WOODRUFF A	7000 TO, BUT NOT INCL 8000 MSL	SR-SS WD/ATIN	MEMPHIS CNTR
WOODRUFF B	7000 TO, BUT NOT INCL 8000 MSL	SR-SS WD/ATIN	MEMPHIS CNTR

*MSL unless otherwise indicated.

MILITARY TRAINING ROUTES (MTR's)

All IR and VR MTRs are shown, and may extend from the surface upwards. Only the route centerline, direction of flight along the route, and the route designator are charted. Route widths vary from 4 to 10 miles.

Since these routes are subject to change every 56 days, pilots are cautioned and advised to contact Flight Service for route dimensions and current status for MTRs that may affect their flight.

Routes with a change in the alignment of the charted route centerline will be identified by the addition of a new route designator for the new centerline.

DoD users refer to Area Planning AFR/AN Military Training Routes North and South America for current routes.

CAUTION: Severe turbulence may occur over rugged terrain. See AIM.

CAUTION: This chart is primarily designed for VFR navigational purposes and does not depict all obstacles. Pilots should not rely solely upon information found on this chart because terrain or obstacles which may be encountered below reasonable and safe altitudes.

CONTOUR INTERVAL AND ELEVATIONS

CONTOUR INTERVAL 500 feet
Intermediate contours 250 feet
Supplementary contours 100 feet
HIGHEST TERRAIN elevation is 2752 feet located at 35° 10'N - 93° 39'W
Spot elevation 4054
Approximate elevation 4300

CONVERSION OF ELEVATIONS

FEET (Thousands) 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31
METERS 0 1 2 3 4 5 6 7 8 9

ATTENTION

THIS CHART CONTAINS MAXIMUM ELEVATION FIGURES (MEF). The Maximum Elevation Figure is shown in quadrangles bounded by lines of latitude and longitude. Each quadrangle covers 10 minutes (10 HUNDREDS of feet above mean sea level). The MEF is based on the highest known feature in the quadrangle, including terrain and obstructions (trees, towers, antennas, etc.).

Example: 12,056 feet **12 5**

Flight Following Services are available on request and highly recommended in and around Class B, C, and TRSA areas.

REPORTING CHART ERRORS

You are requested to inform us of chart errors and/or additions that come to your attention. Please write to: Chart Feedback, Aeronautical Information Services, or via our website at: http://faa.gov/air_traffic/flight_info/aeronav/. See the FAAs prior to contact via toll free number or email. Telephone toll free at 1-800-638-8972, or email us at: 9-AMC-AeroChart@faa.gov. Mail to: Aeronautical Charting Group, Customer Operations Team, 1305 East-West Highway, SSMC 4, Suite 4400, Silver Spring, MD 20910-3281.

FOR PROCUREMENT

Contact an Authorized FAA Chart Sales Agent, or the Aeronautical Charting Group web site on Visual Flight Chart/Publication Sales. For digital products, visit: https://www.faa.gov/air_traffic/flight_info/aeronav/digital_products/

REGULATIONS REGARDING FLIGHTS OVER CHARTED NATIONAL PARK SERVICE AREAS, U.S. FISH AND WILDLIFE SERVICE AREAS, AND U.S. FOREST SERVICE AREAS

The landing of aircraft is prohibited on lands or waters administered by the National Park Service, U.S. Fish and Wildlife Service, and U.S. Forest Service without authorization from the respective agency. Exceptions include an "in-flight" emergency that is beyond the control of the operator. (Ex: in-flight emergency, weather, etc.) "NEM" section 3-6.2 of the manual prohibits operations. Additionally, if a U.S. military fighter jets intercept an aircraft and there are displeased in the area of that aircraft, aviators will follow the instructions given by the intercepting aircraft or signals. If the aircraft is equipped with radio, it will tune in on VHF guard 121.5 or UHF 243.0 and follow the interceptor visual EVS signals. Be advised that non-compliance may result in the use of force.

NORTH AMERICAN AEROSPACE DEFENSE COMMAND DOMING PROCEDURES

All aircraft operating in the U.S. national airspace, if capable, will maintain a following watch on guard frequencies (RP 121.5 or UHF 243.0. It is incumbent upon pilots to be familiar with the procedures outlined in the Aeronautical Information Manual. "VMC" section 5-6-2 of the manual procedures. Additionally, if a U.S. military fighter jets intercept an aircraft and there are displeased in the area of that aircraft, aviators will follow the instructions given by the intercepting aircraft or signals. If the aircraft is equipped with radio, it will tune in on VHF guard 121.5 or UHF 243.0 and follow the interceptor visual EVS signals. Be advised that non-compliance may result in the use of force.

CLASS G AIRSPACE

Class G Airspace within the United States extends up to, but not including, 1,200 feet above the surface of the earth within Class E Airspace, excluding the airspace less than 1000 feet above the terrain and certain special use airspace areas.

MEMPHIS SECTIONAL
SECTIONAL AERONAUTICAL CHART SCALE 1:500,000

Federal Aviation Administration

96TH EDITION EFFECTIVE 0901Z 31 MAR 2016
TO 0901Z 15 SEP 2016

Includes airspace amendments effective 31 MAR 2016
and all other aeronautical data received by 4 FEB 2016

Information on this chart will change; consolidated major updates of chart changes are available every 56 days in the Digital Products section of the FAA Publications website. Use this chart for navigation in the area bounded by the heavy magenta line.
NOTICES TO AIRMEN (NOTAMs) and other FLIGHT INFORMATION PUBLICATIONS (FLIPs) list the latest changes.

PUBLISHED IN ACCORDANCE WITH INTERAGENCY AIR CARTOGRAPHIC COMMITTEE SPECIFICATIONS AND AGREEMENTS, APPROVED BY: DEPARTMENT OF DEFENSE / FEDERAL AVIATION ADMINISTRATION

Warning: Refer to current foreign charts and flight information publications for information within foreign airspace.

FAA Product ID: SMEM
NSN 7641014100162
SECX/MEMPHIS
16091

PLOTTING DIRECT ROUTE ON NORTH/SOUTH SIDE

There are approximately two minutes of latitude overlap between the north and south sides of each sectional/TERMINAL chart. To plot a course line from one side to the other, the user must first locate two points of equal latitude, one point on each side of the chart. Then follow the steps listed below.

STEP 1 - Draw a horizontal line (MATCH LINE) between each pair of corresponding latitude lines on the north and south sides of the chart. To the right of where your plot line crosses, (Figure 1), label the point of intersection with the name of the airport, airport or destination point closest to the edge of the chart. Label the point on the opposite MATCH LINE along the MATCH LINE (the upper should be exactly parallel on the chart, not extending beyond its edge).

STEP 2 - Place the straight edge of a piece of paper so that it aligns with the two points (POINT A and POINT A') and draw a line from POINT A to the edge of the chart. Label this line LINE A. Repeat this step for POINT B on an edge of the paper where it meets that point.

STEP 3 - Without moving the papers, on the same edge as MARK A, extend a short line on the chart and paper. Label the line MARK A. Label the MATCH LINE out to the edge of the chart. Make the same mark on the paper.

STEP 4 - Turn the chart over and transfer the end of LINE A and MARK A to the opposite edge of the MATCH LINE. (Figure 2).

STEP 5 - Take the chart or paper with MARK A on it and place the edge of the paper so that it aligns with the MATCH LINE and LINE A (LINE A will be extended). Draw a line from MARK A to the departure or destination point (POINT B).

STEP 6 - Where the line drawn in STEP 5 crosses the MATCH LINE make a MARK C. Extend a line straight from that mark to the edge of the chart.

STEP 7 - Turn the chart back over and transfer MARK C to that side and extend it to the MATCH LINE. Place a line from MARK C to the destination. (Figure 3).



MEMPHIS