D-ATIS
127.9 251.15
HONOLULU TOWER
118.1 257.8
123.9 273.575 (RWY 08R-26L)
GND CON
121.9 348.6
GND CON (RAMP CON)
121.8
CLNC DEL
121.4
D
JOINT BASE PEARL HARBOR-HICKAM
CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.
ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.
JANUARY 2015
ANNUAL RATE OF CHANGE
0.0° W
VAR 9.6° E
157°57'W
157°56'W
157°55'W
21°20'N
21°19'N
HICKAM RAMP ADVISORY
AIR FREIGHT
TERMINAL
BASE OPS
FIRE STATION
TRAN ALERT
HAWAII ANG
HAZARDOUS CARGO PAD
FIELD ELEV 13
12312 X 150
080.4°
260.4°
TWR 190
FIRE STATION
LAHSO
705 X 150
GENERAL AVIATION CARGO
3000 X 150
5000 X 300
CALIBRATION PAD
12000 X 200
BAK-12/14
HS 1
HS 2
HS 3
HS 4
HS 5
HS 6
RWY 04L-22R
PCN 31 F/B/X/T
S-100, D-200, 2D-400, 2D/D1-450, 2D/2D2-850
RWY 04R-22L
PCN 57 F/B/X/T
S-100, D-200, 2D-400, 2D/D1-450, 2D/2D2-850
RWY 08L-26R
PCN 79 R/B/W/T
S-100, D-200, 2T-345, 2D-400, 2D/D1-400, 2D/2D2-780, C5-840
RWY 08R-26L
PCN 98 F/B/X/T
S-80, D-170, 2D-400, 2D/D1-415, 2D/2D2-780, C5-780