

# WORTH ONE DEPARTURE



## DEPARTURE ROUTE DESCRIPTION

TAKEOFF RWYS 16, 17: Climb heading 164° to 1600 before proceeding on course.

When entering controlled airspace, fly assigned heading and altitude, expect vector to appropriate route.

ABILENE TRANSITION (WORTH1.ABI): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC.

BOOMR TRANSITION (WORTH1.BOOMR): From over TTT VOR/DME on TTT R-275 to MANKI, then on GTH R-119 to OWING, then on LBB R-085 to BOOMR.

CHILDRESS TRANSITION (WORTH1.CDS): From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC.

CORONA TRANSITION (WORTH1.CNX): From over TTT VOR/DME on TTT R-264 to KIRST, then on LBB R-102 to LBB VORTAC, then on LBB R-272 and CNX R-088 to CNX VORTAC.

GUTHRIE TRANSITION (WORTH1.GTH): From over TTT VOR/DME on TTT R-275 to MANKI, then on GTH R-119 to GTH VORTAC.

LUBBOCK TRANSITION (WORTH1.LBB): From over TTT VOR/DME on TTT R-264 to KIRST, then on LBB R-102 to LBB VORTAC.

MILLSAP TRANSITION (WORTH1.MQP): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC.

PANHANDLE TRANSITION (WORTH1.PNH): From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC, then on CDS R-297 and PNH R-118 to PNH VORTAC.

PODDE TRANSITION (WORTH1.PODDE): From over TTT VOR/DME on TTT R-250 to PODDE.

TEXICO TRANSITION (WORTH1.TXO): From over TTT VOR/DME on TTT R-264 to KIRST, then on LBB R-102 to LBB VORTAC, then on LBB R-305 and TXO R-124 to TXO VORTAC.

TUCUMCARI TRANSITION (WORTH1.TCC): From over TTT VOR/DME on TTT R-275 to MANKI, then on GTH R-119 to GTH VORTAC, then on track 286° to TCC VORTAC.

NOTE: BOOMR TRANSITION: For aircraft inbound to the Lubbock Terminal area, DME required.

NOTE: PODDE TRANSITION: ATC assigned.

NOTE: TUCUMCARI TRANSITION: GTH VORTAC to TCC VORTAC, GPS required.

SC-2, 20 JUN 2019 to 18 JUL 2019

SC-2, 20 JUN 2019 to 18 JUL 2019