

	DEPARTURE ROUTE DESCRIPTION
	<p>When entering controlled airspace, fly assigned heading for RADAR vectors to appropriate route. Maintain ATC assigned altitude.</p> <p><u>ABILENE TRANSITION (WORTH1.ABI):</u> From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC.</p> <p><u>CHILDRESS TRANSITION (WORTH1.CDS):</u> From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC.</p> <p><u>CORONA TRANSITION (WORTH1.CNX):</u> From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC, then on LBB R-272 and CNX R-088 to CNX VORTAC.</p> <p><u>LUBBOCK TRANSITION (WORTH1.LBB):</u> From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC.</p> <p><u>PANHANDLE TRANSITION (WORTH1.PNH):</u> From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC, then on CDS R-297 and PNH R-118 to PNH VORTAC.</p> <p><u>PODDE TRANSITION (WORTH1.PODDE):</u> From over TTT VOR/DME on TTT R-250 to PODDE.</p> <p><u>TEXICO TRANSITION (WORTH1.TXO):</u> From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC, then on LBB R-305 and TXO R-124 to TXO VORTAC.</p>