

# DALLAS FIVE DEPARTURE

DALLAS, TEXAS



## DEPARTURE ROUTE DESCRIPTION

When entering controlled airspace, fly assigned heading and altitude, for vector to appropriate route.

BELCHER TRANSITION (DALL5.EIC): From over TTT VOR/DME on TTT R-094 to POTEN, then on EIC R-259 to EIC VORTAC.

EL DORADO TRANSITION (DALL5.ELD): From over TTT VOR/DME on TTT R-084 to SOLDO, then on UIM R-261 to UIM VOR/DME, then on UIM R-072 and ELD R-254 to ELD VOR/DME.

LITTLE ROCK TRANSITION (DALL5.LIT): From over TTT VOR/DME on TTT R-064 to ORTRO, then on LIT R-235 to LIT VORTAC.

MERIDIAN TRANSITION (DALL5.MEI): From over TTT VOR/DME on TTT R-084 to SOLDO, then on UIM R-261 to UIM VOR/DME, then on UIM R-072 and ELD R-254 to ELD VOR/DME, then on ELD R-097 and MEI R-281 to MEI VORTAC.

QUITMAN TRANSITION (DALL5.UIM): From over TTT VOR/DME on TTT R-084 to SOLDO, then on UIM R-261 to UIM VOR/DME.

SAWMILL TRANSITION (DALL5.SWB): From over TTT VOR/DME on TTT R-094 to POTEN, then on EIC R-259 to TEKBE, then on SWB R-291 to SWB VOR/DME.

SIDON TRANSITION (DALL5.SQS): From over TTT VOR/DME on TTT R-084 to SOLDO, then on UIM R-261 to UIM VOR/DME, then on UIM R-072 and ELD R-254 to ELD VOR/DME, then on ELD R-077 and SQS R-262 to SQS VORTAC.

SOLDO TRANSITION (DALL5.SOLDO): From over TTT VOR/DME on TTT R-084 to SOLDO.

TEXARKANA TRANSITION (DALL5.TXK): From over TTT VOR/DME on TTT R-074 to SHERO, then on TXK R-244 to TXK VORTAC.

NOTE: BELCHER TRANSITION: For aircraft inbound to the JAN, MLU and SHV terminal areas only.

NOTE: EL DORADO TRANSITION: For aircraft inbound to the Memphis terminal area.

Aircraft should file and/or expect the appropriate STAR.

NOTE: MERIDIAN TRANSITION: For aircraft inbound to the Atlanta terminal area.

NOTE: QUITMAN TRANSITION: For aircraft inbound to Shreveport terminal area.

NOTE: SOLDO TRANSITION: ATC assigned.

SC-2, 26 MAR 2020 to 23 APR 2020

SC-2, 26 MAR 2020 to 23 APR 2020