

# PRM APPROACH AAUP

## ATTENTION ALL USERS PAGE (AAUP)

**Pilots who are unable to participate** will be afforded appropriate arrival services as operational conditions permit and must notify the controlling ATC facility as soon as practical, but at least 100 miles from destination.

Simultaneous PRM approaches will only be offered/conducted when the weather is at least 1600 feet (ceiling) and 4 miles (visibility).

- ILS PRM Rwy 28L
- RNAV (GPS) PRM Rwy 28L
- LDA PRM Rwy 28R
- RNAV (GPS) PRM X Rwy 28R

### General

Review procedure for executing a climbing and descending PRM breakout

Breakout phraseology: "TRAFFIC ALERT (call sign) TURN (left/right) IMMEDIATELY HEADING (degrees) CLIMB/DESCEND AND MAINTAIN (altitude)."

All breakouts: Hand flown, initiate immediately.

Descending on the glideslope/glidepath ensures compliance with any charted crossing restrictions.

Dual VHF Comm.: When assigned or planning a specific PRM approach, tune a second receiver to the PRM monitor frequency or, if silent, another active frequency (i.e. ATIS), set the volume, retune the PRM frequency if necessary, then deselect the audio. When directed by ATC, switch to the appropriate approach control frequency and select the second receiver audio to ON.

Runway 28R: NORCAL approach 120.35  
Runway 28L: NORCAL approach 135.65

If later assigned the same runway, non-PRM approach, consider it briefed provided the same minimums are utilized. PRM related chart notes and PRM frequency no longer apply.

TCAS during breakout: Follow TCAS climb/descend if it differs from ATC, while executing the breakout turn.

### Runway Specific

#### ILS PRM Rwy 28L: Straight-in Approach

Briefing Points: (Note: Identify NEPIC WP as 3.3 NM from Rwy 28L WP if not in the FMC approach coding.)

- Inside NEPIC, descending on (not above) the glidepath benefits the trailing 28R aircraft to avoid wake turbulence.
- Other aircraft may be conducting the PRM approach to runway 28R. These aircraft will approach from the right-rear and will re-align with runway 28R after making visual contact with the runway 28L landing traffic.
- Expect to be switched to SFO tower at NEPIC.
- PRM monitor frequency may be de-selected after determining that the aircraft is on the tower frequency.

CONTINUED ON FOLLOWING PAGE

SW-2, 03 JAN 2019 to 31 JAN 2019

SW-2, 03 JAN 2019 to 31 JAN 2019