

VOR/DME EAT <b>114.35</b> Chan <b>90(Y)</b>	APP CRS <b>289°</b>	Rwy Ldg TDZE Apt Elev <b>N/A</b> <b>N/A</b> <b>1249</b>
---	------------------------	--

VOR-A

PANGBORN MEML (EAT)

<div><div><div>▼</div><div>▲</div><div>❄</div></div><div><div>DME required.</div><div>Circling NA northeast of Rwy 12-30.</div></div></div> <div>MISSED APPROACH: Climb to 3900 then climbing left turn to 6000 direct EAT VOR/DME and hold, continue climb-in-hold to 6000.</div>
--

ASOS <b>119.925</b>	SEATTLE CENTER <b>126.1</b>	UNICOM <b>123.0</b> (CTAF) <b>0</b>
------------------------	--------------------------------	--

