

LOC/DME I-ABR  
**109.9**  
Chan 36

APP CRS  
**308°**

Rwy Idg  
TDZE  
Apt Elev  
**6901**  
**1301**  
**1302**


ILS or LOC RWY 31  
ABERDEEN RGNL (ABR)

ADF required.  
For inop ALS, increase S-LOC 31 Cats C/D  
visibility to 1 SM.

MALSR  
AS

MISSED APPROACH: Climb to 3000 then right turn direct  
RENEY LOM/I-ABR 6.1 DME and hold.

ASOS <b>125.875</b>	MINNEAPOLIS CENTER <b>120.6 371.9</b>	UNICOM <b>122.7 (CTAF)</b>
------------------------	--	-------------------------------



ELEV 1302 TDZE 1301

HIRL Rwy 13-31  
MIRL Rwy 17-35  
REIL Rwy 13, 17 and 35  
1412

FAF to MAP 4.8 NM

Knots	60	90	120	150	180
Min:Sec	4:48	3:12	2:24	1:55	1:36

3000

AB

Use I-ABR DME when on LOC course.

AB RENEEY LOM I-ABR 6.1

Remain within 10 NM

128°

308°

3000

GS 3.00°

TCH 64

0.9 NM

3.9 NM

2908

I-ABR 1.4

\* I-ABR 2.3

\* LOC only.

CATEGORY	A	B	C	D
S-ILS 31	1501-½ 200 (200-½)			
S-LOC 31	1660-½ 359 (400-½)		1660-⅝ 359 (400-⅝)	1660-¾ 359 (400-¾)