

LOC/DME BC RWY 10
NOME (OME) (PAOM)

MISSED APPROACH: Climb to 3000
direct OME VOR/DME and hold,
continue climb-in-hold to 3000.

DME REQUIRED

MIRL Rwy 3-21

MIRL Rwy 10-28

REIL Rwys 3 and 10

