


VOR RWY 20R
KENAI MUNI (ENA) (PAEN)

MALSR

MISSED APPROACH:
Climb to 2200 on ENA
VOR/DME R-192 to DIXIT/ENA
VOR/DME 10 DME and hold.



KENAI MUNI (ENA) (PAEN)
VOR RWY 20R