

LOC/DME I-TYR <b>111.95</b> Chan 56 (Y)	APP CRS <b>042°</b>	Rwy Idg TDZE Apt Elev	<b>7734</b> <b>542</b> <b>544</b>
---	------------------------	-----------------------------	---

ILS or LOC RWY 4  
TYLER POUNDS RGNL (TYR)

DME required. For inop ALS increase S-LOC 4 Cat C/D visibility to 1 SM.	MALSR 	MISSED APPROACH: Climb to 1100 then climbing right turn to 2500 on TYR VOR/DME R-087 to OTTIF/TYR 9.5 DME and hold.
--	-----------	---

ATIS <b>126.25</b>	LONGVIEW APP CON ★ <b>128.75 379.15</b>	POUNDS TOWER ★ <b>120.1 (CTAF) 257.8</b>	GND CON <b>121.9</b>	UNICOM <b>122.95</b>
-----------------------	--	---	-------------------------	-------------------------

